


To calculate vertical clearances, subtract the current water surface elevation from the structure's elevation.



To calculate vertical clearances, subtract the current water surface elevation from the structure's elevation.