




To calculate vertical clearances,
 subtract the current water surface
 elevation from the structure's elevation.



To calculate vertical clearances subtract the current water surface elevation from the structure's elevation.