





National Dredging Quality Management Program

QUICK GUIDE: DQM VIEWER – VIEWING PROJECT DATA



View Active Project

Click on a location icon on the map to view current project information.



Select Data
 Displays the Selectron to select and view data.



- Sort and Select by:
1. District/Contract
 2. Project Area
 3. Dredge Type/Plant Name
 4. Year/Month/Day

Note: You can change the filter order of the results by dragging and dropping the columns in any order. Selections are typically made from left to right to filter results in the remaining columns, but column selections can be made in any order.

Select Data/View All or Specific Tracks

Click **Browse Project** to select a specific track. The Select Data screen (Selectron) displays, with the contract and project area pre-selected.



Next, Select:

1. The Plant Name
2. The Date: Year, Month, and Day
3. If the dredge type is a pipeline, double click on the desired day. If the dredge type is a hopper or scow:
 - a. Select either Cycle (calculated) or Load (reported).
 - b. Double click on desired cycle/load.

View Plant's Latest Track

Click **View Current Track** for the latest track. The Select Data screen (Selectron) displays, with the contract and project area selected.



Selected Load